Intro <u>Top</u> <u>Next</u>

I recommend you to use MSDN (Microsoft Developer Network)!

This tutorial is about Visual Basic native code not P-CODE.

VISUAL BASIC is a high level programming language.

BASIC stands for "Beginners All-purpose Symbolic Instruction Code".

#### Types of data in Visual Basic:

## 1. Byte (UI1)

- can keep a value from 0 to 255 and is equivalent with ASCII code of one char, stored as 1 byte

## 2. Int (I2 - integer) (symbol: %)

- can keep a value from -32768 to 32767, stored as 2 bytes (word)

## 3. Long (I4 -long integer) (symbol: &)

- can keep a value from -2147483648 to 2147483647, stored as 4 bytes (dword)

## 4. Single (R4 - single real) (symbol: !):

Single-precision floating-point variables as 32-bit (4-byte) floating-point numbers, ranging in value

from -3.402823E38 to -1.401298E-45 for negative values, and 1.401298E-45 to 3.402823E38 for

positive values

## 5. Double (R8 - double real) (symbol: #):

Double-precision floating-point numbers as 64-bit numbers in the range -1.79769313486232E308 to 4.94065645841247E-324 for negative values; 4.94065645841247E-324 to 1.79769313486232E308 for positive values

# 6. String (Str/Bstr) (symbol: \$)

- can store up to 65000 chars, used memory depend on string size

#### 7. Bolean:

The bolean in Visual Basic has 2 value: True = 0FFFFh and False = 0. Memory requirement: two bytes

# 8. Curency (Cy) (symbol: @):

It is a data type with a range of -922,337,203,685,477.5808 to 922,337,203,685,477.5807.

Use this data type for calculations involving money and for fixed-point

calculations where

accuracy is particularly important.

#### **9. Date**:

Eight bytes time information.

Range: 1/1/100 to 12/31/9999

A variant of type date is in Visual Basic is internally stored as a double (real number) - strange thing!

So when we have a date we have a qword, butt in functions with date will be only the offset of qword.

The variant of type date is composed by date+time, the date is the integer portion of the real number,

the fractional part is the time.

When in VB we have time the integer portion is zero.

Adding integers to a Date variable is equivalent to adding days, because the integer portion

of a Date variable represents the number of days that have passed since December 30, 1899.

## 10. Object:

A object can be: Instances of classes, OLE objects

Object variables are stored as 32-bit (4-byte) addresses that refer to objects within an application or within some other application.

Dim objDb As Object 'declare a variable as object

Set objDb = OpenDatabase("c:\Vb5\Biblio.mdb") 'assign the value to refer a object

When declaring object variables, try to use specific classes (such as TextBox instead of Control

or, in the preceding case, Database instead of Object) rather than the generic Object.

Visual Basic can resolve references to the properties and methods of objects with specific

types before you run an application. This allows the application to perform faster at run

time. Specific classes are listed in the Object Browser.

# 11. Array

Arrays allow you to refer to a series of variables by the same name and to use a number (an index)

to tell them apart. This helps you create smaller and simpler code in many situations, because you

can set up loops that deal efficiently with any number of cases by using the index number.

Arrays have both upper and lower bounds, and the elements of the array are contiguous within

those bounds. Because Visual Basic allocates space for each index number, avoid declaring

an array larger than necessary.

All the elements in an array have the same data type. Of course, when the data type is Variant,

the individual elements may contain different kinds of data (objects, strings, numbers, and so on).

In Visual Basic there are two types of arrays: a fixed-size array which always remains

the same size, and a dynamic array whose size can change at run-time.

## **12. Variant** (any of the preceding data types):

Variant data type is a special data type that can contain any system-defined types of data:

numeric, string, or date, as well as user-defined types and the special values Empty and Null.

The Variant data type has a numeric storage size of 16 bytes and can contain data up to

the range of a Decimal, or a character storage size of 22 bytes (plus string length), and can

store any character text.

You don't have to convert between these types of data if you assign them to a Variant variable;

Visual Basic automatically performs any necessary conversion. For example:

Dim SomeValue 'variant by default or you can declare as Variant

SomeValue = "17" 'SomeValue contains "17" (a two-character string).

SomeValue = SomeValue - 15 ' SomeValue now contains the numeric value 2.

SomeValue = "U" & SomeValue ' SomeValue now contains "U2" (a two-character string)

#### The Empty Value:

A Variant variable has the Empty value before it is assigned a value.

The Empty value is a special value different from 0, a zero-length string (""), or the Null value!!!

If IsEmpty(Z) Then Z = 0 ' test if variant Z is Empty

The Empty value disappears as soon as any value (including 0, a zero-length string, or Null) is

assigned to a Variant variable. You can set a Variant variable back to Empty by assigning the keyword Empty to the Variant.

#### The Null Value:

The Variant data type can contain another special value: Null. Null is commonly used in database

applications to indicate unknown or missing data.

Z = Null' set variant Z to Null

If you assign Null to a variable of any type other than Variant, a trappable error occurs.

Assigning Null to a Variant variable doesn't cause an error, and Null will propagate through

expressions involving Variant variables (though Null does not propagate through certain functions).

You can return Null from any Function procedure with a Variant return value.

Variables are not set to Null unless you explicitly assign Null to them, so if you don't

use Null in your application, you don't have to write code that tests for and handles it.

#### The Error Value:

In a Variant, Error is a special value used to indicate that an error condition has occurred in a

procedure. However, unlike for other kinds of errors, normal application-level error handling does

not occur. This allows you, or the application itself, to take some alternative

based on the error

value. Error values are created by converting real numbers to error values using the CVErr function.

When you want to see parameters of Visual Basic functions execute the code until EIP is equal

with address of the function, now look on the Stack Windows in Olly. I sad this because Visual Basic has a lot of obfuscated code.

#### SmartCheck functions:

Val() - convert string to number

**Str**\$() - convert number to string

**Left\$()** - substring from left end e.g. Left\$(Theodolite, 4) = "Theo"

**Right\$()** - substring from right end

**Ltrim**\$() - rtcLeftTrimBstr(string) - trim spaces off left e.g. Ltrim\$ (" Hello ") = "Hello "

**Rtrim**\$() - rtcRightTrimBstr(string) - trim spaces off right

Trim\$() - rtcTrimBstr(string) - trim spaces off both ends

Mid() - rtcMidCharVar

Mid\$(String:"araqmuP", long:1 - this is number of letter in the araqmuP string,

VARIANT:Integer:1 - this is number of chars the function must take)

In VB code this will look like this: letter = Mid\$("araqmuP", 1, 1)

Asc() - rtcAnsiValueBstr - convert char to decimal ASCII value e.g. Asc("A") = 65

Chr\$() - rtcBstrFromAnsi - convert ANSI code to char e.g. Chr\$(65) = "A", returns a string

**Hex** - rtcHexVarFromVar

**Len** - \_\_vbaLenBstr - length of string

Long - vbaI2I4

**OnError** - \_\_vbaOnError - used for error handling

**LCase**\$(String) - rtcLowerCaseBstr - convert string to lowercase

UCase\$(String) - rtcUpperCaseBstr - convert string to uppercase

Rnd() - rtcRandomNext - return a random number

**ReDim** - re-allocate memory or stuffs - that's not really important to us **IsNumeric** returns Boolean:True - check if a string is a numeric value

**Abs()** - returns a value of the same type that is passed to it specifying the absolute value of a number

**VariantChangeTypeEx** - used to change the type of a variable, probably the variable will be comparated

LoadResData - load resources

Almost every string operation returns a Variant data type except Len. For each of them, there is an identical function with a dollar sign (\$) at the end of the function's name to indicate a String type return value. I recommend using the \$ versions (such as Left\$) whenever possible because they are more efficient.

#### Apis from OLEAUT32.DLL:

# SysAllocStringByteLen(LPSTR:004103F0, DWORD:00000002) returns LPVOID:410434

## **Explanation**:

String from **004103F0** is copied to new memory location 00410434 It is usually followed by \_\_vbaStrVarVal(VARIATN:String"?") returns DWORD:410434

# SysAllocStringLen(PTR:00000000, DWORD:00000029) returns LPVOID:410584

Allocate memory with size 29 and return a pointer to the memory

## SysFreeString(BSTR:00410584)

# Explanation:

- the string located at memory location 00410584 is cleared (free memory location 00410584)

These lines are especially good for "serial fishing" because when you click on them and look at the right window, you will see what Strings are being freed. Correct codes/serials are sometimes shown here.

#### VarNumFromParseNum:

- this procedure returns our dummy code converted into a double real number

Decompiling the VB code:

In VB the right address of variants (Var) are at address\_showed-8. Strings (Str) have the right

address showed.

If we have as parameter a variant with subtype string this behaves as in variants (Var) case.

#### Example:

00402549 LEA ECX, DWORD PTR SS: [EBP-48]

0040254C LEA EDX,DWORD PTR SS:[EBP-58]

0040254F PUSH ECX; ECX = address of number to be converted-8; address of real variable = ECX+8

00402550 PUSH EDX; address of destination string

00402551 MOV DWORD PTR SS:[EBP-40],0B; set the value of number to be converted

00402558 MOV DWORD PTR SS:[EBP-48],2; the type of variable 0040255F CALL MSVBVM60.rtcHexVarFromVar

NuMega SmartCheck (great debugger) utilisation:
After you load the program, maximize the window, start the program (F5)
you must chose the "Show All Events" button (to make SC to show all events)!!!

Motto:

If Visual Basic Then cracked at once

API <u>Previous Top Next</u>

#### ThunRTMain:

Entry point of every VB program start with: 00401038 push offset EXEPROJECTINFO 0040103D call MSVBVM60:ThunRTMain

The ThunRTMain (the Thunder Runtime Engine) function exported by VB runtime DLL reads

the EXEPROJECTINFO structure and starts VB project initialization. The structure contains

a lot of important information, such as the address of the Main() function.

The VB runtime

will eventually call this address (if it is defined).

More information in "VISUAL BASIC STRUCTURE".

For VB6:

**734347D4** call dword ptr [esi+94]; enter inside this one and you will find the main() function

# API for comparing:

- 1. **vbaStrCmp**(String:"xxxxx", String:"yyyyy") returns DWORD:0
- used for comparing strings "xxxxx" and "yyyyy"
- returns in ax 0 if comparated strings are equal else ax=0FFFFh (True)
- can be used to test if a string is empty by comparing string with Null string (00h)

```
__vbaStrTextCmp, __vbaVarTextCmp, __vbaVarTextTst,
__vbaStrComp,
__vbaStrCompVar - use in the same way for comparing 2 strings
2.__vbaVarTstEq(VARIANT1, VARIANT2) returns DWORD:0
- is used to compare variants
- if they are the same ax=0FFFFh (True) else ax=0 (False), __vbaVarTstNe
```

- if they are the same ax=0FFFFh (True) else ax=0 (False), \_\_vbaVarTstNe is the reverse function
- similar with \_\_vbaVarCmpEq

\_vbaVarCmpEq/\_\_vbaVarCmpGe/\_\_vbaVarCmpGt/\_\_vbaVarCmpLe/ /\_\_vbaVarCmpLt/\_\_vbaVarCmpNe

- is used to compare 2 variants
- Eq = equal; Ge = Greater or equal (>=); Gt = Greater (>); Le = Little or equal (<=); Lt = Little (<);

Ne = not equal

- if the condition is ok will set ax to 0FFFFh (True) else to 0 (False)
- 4. \_\_vbaFpCmpCy floating point compare currency
- 5. \_\_vbaInStrVar/\_\_vbaInStr returns a long specifying the position of the first occurrence

of one string within another, if no occurrence returns 0

in VB: FindPos = InStr("KILLER", Chr\$(13))

(translated to vbaInStrVar)

in VB: FindPos = InStr("KILLER", "LL")

(translated to vbaInStr)

InStr has two optional parameters: first parameter start position and last parameter comparation method.

Start position must start from 1 (1 is the first char).

**rtcInStrRev** - returns the position of an occurrence of one string within another, from the end of string

In VB: FindPos = InstrRev(string1,string2,start,compare)

- 6. \_\_vbaBoolVarNull tests if a variable is null, if is null returns 0 else returns 0FFFFh (-1),
- as parameter is pushed the right address of variable!
- 7. **rtcIsNull** returns a Boolean value that indicates whether an expression contains no valid data (Null)

Null = no valid data

In VB:

Dim MyVar, MyCheck

MyCheck = IsNull(MyVar) ' returns False

MyVar = Null 'assign Null.

MyCheck = IsNull(MyVar) ' returns True

MyVar = Empty 'assign Empty

MyCheck = IsNull(MyVar) ' returns False

8. **rtcIsEmpty** - returns a Boolean value indicating whether a variable has been initialized, returns

TRUE if variant was initialized with Null

Empty = uninitialized

If IsEmpty(Z) Then Z = 0

9. **rtcIsNumeric** - returns a Boolean value indicating whether an expression can be evaluated as a number

In VB:

Dim MyVar, MyCheck

MyVar = 53 'assign a value.

MyCheck = IsNumeric(MyVar) ' returns True.

MyVar = "459.95" 'assign a value

MyCheck = IsNumeric(MyVar) ' returns True

MyVar = "459.95 TEST" ' assign a value

MyCheck = IsNumeric(MyVar) ' returns False

rtcIsArray, rtcIsDate, IsObject - as rtcIsNumeric but test if is a array/date/object

# API for strings:

- 1. **vbaStrVarVal**(string, variant)
- convert variant to string and place them in a string
- ECX source (variant), EDX destination (string)
- 2. **vbaStrCat**(string1, string2)
- concatenate string1 and string2
- 3. \_\_vbaLenVar(receiver, variant)
- push in receiver length of variant
- 4.\_\_vbaLenBstr(string) returns long
- returns in eax length of any string, in VB: len(string)
- 5. \_vbaLenBstrVar(receiver, string)
- push in receiver length of string
- 6. rtcUpperCaseBstr(string)
- converts the string to upper case

In VB: UCase(string)

- 7. rtcLowerCaseBstr(string)
- converts the string to lower case

In VB: LCase(string)

8. int MultiByteToWideChar(

UINT CodePage, // code page

DWORD dwFlags, // character-type options

LPCSTR lpMultiByteStr, // address of string to map

int cchMultiByte, // number of characters in string

LPWSTR lpWideCharStr, // address of wide-character buffer int cchWideChar // size of buffer );

- MultiByteToWideChar converts a ASCII string to a UNICODE string e.g. we have the string "Bob" witch is 426F6200h and after conversion will be "B.o.b.."
- 42006F00620000h. (Don't confuse the '.' with the full stop, I'm using it to represent the null character).

WideCharToMultiByte converts a UNICODE string to a ASCII string \_\_vbaStrToAnsi - convert a wide-char string (UNICODE) string to ASCII (ANSI)

\_\_vbaStrToUnicode - convert a ASCII(ANSI) string to a wide-char string (UNICODE)

- 9. int **rtcMidCharVar**(string, length, position)
- e.g. we have string "1234567890", length = 2, position = 4 then the function returns a pointer to string "45"
- 10. int **rtcLeftCharVar**(string, length)
- e.g. we have string "13567890", length = 3 then the function returns a pointer

to string "135"

- 11. int rtcRightCharVar(string, length)
- e.g. we have string "13567890", length = 4 then the function returns a pointer

to string "7890"

- 12. rtcLeftCharBstr(string, length) as String
- e.g. we have string "13567890", length = 4 then the function returns a pointer

to string "135"

13. **rtcAnsiValueBstr**(position, string) - convert to ANSI (number) the char witch specified position

from string and returns the number in eax

- for exemple Asc("A") = 65
- 14. **rtcHexVarFromVar**(buffer, number) set buffer with a string representing the hexadecimal value of a number

Example: 123 => 31 00 32 00 33 00 00 00

(wide chars, and just before the string, the length is stored, in this case: 2\*3)

15. **rtcOctVarFromVar**(buffer, number) - set buffer with a string representing the octal value

16. **rtcLeftTrimBstr**(string) returns pointer to string - trim spaces off left e.g. Ltrim\$(" Hello ") = "Hello "

17. **rtcRightTrimBstr**(string) returns pointer to string - trim spaces off right

18. **rtcTrimBstr**(string) returns pointer to string - trim spaces off both ends 19. **rtcSplit** - split a string

In VB: Split(string\_to\_split,delimiter,limit as long,comparation\_method) Big example:

Dim MyString, MyArray, Msg

MyString = "VBXisXfun!"

MyArray = Split(MyString, "x", -1, 1)

'now MyArray(0) contains "VB"; MyArray(1) contains "is" and MyArray(2) contains "fun!".

MsgBox MyArray(0) '-> will show "VB"

20. **rtcJoin** - join a string

In VB - lets join the string from 19. again:

MyString = Join(MyArray, "-") ' now MyString will contain "VB-is-fun!"

21. **rtcReplace** - replace from a string other string, returns a pointer to string

In VB:

 $Replace (expression, find, replace with, start, count, comparation\_method)$ 

' last 3 parameters are optional

22. **rtcFilter** - returns a zero-based array containing subset of a string array based on a specified

filter criteria

In VB: Filter(sourcearray, match, include, comparation\_method) sourcearray - one-dimensional array of strings to be searched match - string to search for

include - boolean value indicating whether to returns substrings that include or exclude match

The array returned by the Filter function contains only enough elements to contain the number of

matched items. No match -> empty array

23. rtcStrReverse - reverse a string

In VB: Str1 = StrReverse("KILLER") ' will result "RELLIK"

24. \_\_vbaLbound - returns the index of the first element in the array

In VB: ilbound = LBound(array)

25. \_\_vbaUbound - returns the index of the last element in the array

In VB: ulbound = UBound(array)

26. \_\_vbaLsetFixstr - left aligns a string within a string variable, or copies a variable of one

user-defined type to another variable of a different user-defined type,

LSet replaces any leftover characters in stringvar with spaces

In VB:

Dim MyString

MyString = "0123456789" 'Initialize string.

Lset MyString = "<-Left" ' MyString contains "<-Left ".

#### 27. vbaFreeStr

- frees a temporary string - set the pointer of string to 0

- \_\_vbafreestr accept only one argument which is the address of the string to be deleted - this argument is ALWAYS passed through ECX

28. \_\_vbaFreeStrList(number\_of\_strings, String1, String2,...) - free a list of temporary strings

29. **rtcSpaceVar** - returns a string consisting of the specified number of spaces

In VB:

Dim MyString

MyString = Space(10) ' returns a string with 10 spaces

30. **rtcStringVar** - returns a repeating character string of the length specified

In VB:

Dim MyString

MyString = String(5, "\*") ' returns "\*\*\*\*\*"

MyString = String(5, 42) ' returns "\*\*\*\*\*"

MyString = String(10, "ABC") ' returns "AAAAAAAAAA"

31. **rtcStrConvVar2** - returns a Variant (String) converted as specified (can convert a string to lower-case)

Syntax: StrConv(string, conversion, LCID)

#### API for conversion:

Val() - convert string to number, Str\$() - convert number to string,

```
CBool(expression) - convert expression to boolean;
CByte, CCur, CDate, CDbl, CInt, CLng, CSng, CStr, Cvar, CVErr(convert to
error) - self explain
Asc() - rtcAnsiValueBstr - convert first char from a string to decimal
ASCII value e.g. Asc("A") = 65
Chr$() - rtcBstrFromAnsi - convert ANSI code to char e.g. Chr$(65) =
"A", returns a string
 vbaR8Str/rtcR8ValFromBstr - convert string to double (real)
vbaStrR8 - convert double (real) to string
_vbaStrI2 - convert integer to string
_vbaStrI4 - convert long to string
vbaI2Str - convert string to byte or integer
_vbaI4Str - convert string to long
vbaR4Str - convert string to single (real)
_vbaR8Str - convert string to double (real)
_vbaI2I4 - convert long to integer (same number)
 vbaUI1I2 - convert integer to byte
vbaI4Var - convert variable to long
VarBstrFromI2 - convert integer to string
VarCyFromStr - convert string to currency
rtcBstrFromFormatVar - convert a variable to a string with a specified
format (in SC: format$)
Format has a lot of useful stuff:
Dim MyTime, MyDate, MyStr
MyTime = #17:04:23#
MyDate = #January 27, 1993#
'Returns current system time in the system-defined long time format:
MyStr = Format(Time, "Long Time")
'Returns current system date in the system-defined long date format:
MyStr = Format(Date, "Long Date")
MyStr = Format(MyTime, "h:m:s") ' Returns "17:4:23".
MyStr = Format(MyTime, "hh:mm:ss AMPM") 'Returns "05:04:23 PM".
MyStr = Format(MyDate, "dddd, mmm d yyyy") ' Returns "Wednesday,'
Jan 27 1993".
' If format is not supplied, a string is returned.
MyStr = Format(23) 'Returns "23".
```

'User-defined formats: MyStr = Format(5459.4, "##,##0.00") 'Returns "5,459.40". MyStr = Format(334.9, "###0.00") 'Returns "334.90". MyStr = Format(5, "0.00%") ' Returns "500.00%".MyStr = Format("HELLO", "<") ' Returns "hello". MyStr = Format("This is it", ">") ' Returns "THIS IS IT". API for data: 1. Functions which copy data from a place to other: You should notice that strings are not really copied to a new location only the reference of them. So basically these functions copy the reference of a string to a new location. After copy the old location is released with vbaFreeVar/ vbaFreeStr vbaVarMove(VARIANT:integer:13, VARIANT:Integer:6) - this move the final result (13) where the value 6 was written (overwriting the value 6): LEA EDX, DWORD PTR SS: [EBP-38] PUSH EDX : at edx+8 is the offset of string CALL MSVBVM60. vbaStrVarMove; returns offset of string MOV EDX, EAX; source LEA ECX, DWORD PTR SS: [EBP-18]; destination ; for almost all function edx = destination, ecx = source (not like in this example) CALL MSVBVM60.\_\_vbaStrMove; copy source into destination **vbaStrCopy** - copy string to memory **vbaVarCopy** or **vbaVarMove** - copy variant to memory **vbaVarDup** - copy variant from source to destination (a new location for string) EDX = source, ECX = destinationAlso exist function for copying data for other variable type: vbaAryMove 2. **vbaVarCat** - join 2 variants together Exemple: \_\_vbaVarCat(VARIANT:String:"aa", VARIANT:String:"bb") returns DWORD:63F974

- join "bb" to "aa" to form "aabb" - this can even add to a string a variant 3. vbaVarForInit(VARIANT:Empty, PTR:0063F920, PTR:0063F91.....) - prepare for() cycle (set a For...Next Loop) There will usually be **vbaVarForNext** somewhere below as well 4. **vbaVarForNext** - used in codes where there is a For... Next... Statement (Loop) 5. Releasing local variables (set them to 0): **vbaFreeVar** - frees a temporary variable, accepts only 1 Argument, which is the address of the variable to be deleted, this argument is ALWAYS passed through ECX - uses the API function imp SysFreeString() from OLEAUT32.DLL that carries out the actual deallocation of a variable vbaFreeVarList(number of var, offset var1, offset var2, ...) - free a list of temporary variables 6. VarPtr(variant) returns a long - get the pointer of variant 7. **vbaRedim** - used at procedure level to reallocate storage space for dynamic array variables In VB: Dim alngNum() As Long ReDim alngNum(0 To 99) ' redimensionate the alngNum to a array that contains 100 elements If you use after ReDim the keyword Preserve you will keep the old contain of array and the function used will be **vbaRedimPreserve** 8. **rtcArray** - returns a Variant containing an array In VB: Dim A A = Array(10,20,30)9. In VB: **Erase** array - reinitializes the elements of fixed-size arrays and deallocates dynamic-array storage space, will be translated into **vbaErase** followed by vbaAryDestruct In VB: Dim NumArray(9) 'construct a array - with vbaAryConstruct2

Dim DynamicArray()

ReDim DynamicArray(9) 'allocate storage space

Erase NumArray 'each element is reinitialized

Erase DynamicArray ' free memory used by array

10. \_\_vbaGenerateBoundsError - is called when the size of array is overflow and generates an error

Arrays have both upper and lower bounds, and the elements of the array are contiguous within those bounds

Visual Basic allocates space for each index number, avoid declaring an array larger than necessary

## 11. Special formatting:

rtcFormatCurrency - FormatCurrency; rtcFormatDateTime -

FormatDateTime; rtcFormatNumber - FormatNumber; rtcFormatPercent - FormatPercent

12. **rtcTypeName** - returns a string that provides Variant subtype information about a variable

In VB:

MyType = TypeName("VBScript") ' returns "String"

13. **rtcVarType** - similar with rtcTypeName butt returns a value indicating the subtype of a variable

#### Math:

\_vbaVarAdd(TARGET, VARIANT1, VARIANT2) - add VARIANT1 to VARIANT2 and put him

in TARGET

\_\_vbaVarSub(VARIANT1, VARIANT2) - sub from VARIANT1 VARIANT2

\_\_vbaVarMul(VARIANT1, VARIANT2) - multiply VARIANT1 with VARIANT2

\_vbaVarDiv(VARIANT1, VARIANT2) - divide VARIANT1 with VARIANT2

\_\_vbaVarIdiv - divide (like before) butt the result will be a integer \_\_vbaVarXor(VARIANT1, VARIANT2) - XOR VARIANT1 with VARIANT2

\_\_vbaVarOr(VARIANT1, VARIANT2) - OR VARIANT1 with VARIANT2

rtcSqr - square from a number, in VB is without rtc

**rtcAbs** - returns a value of the same type that is passed to it specifying the absolute value of a number rtcCos - returns a double specifying the cosine of an angle **rtcAtn** - returns the arctangent of a number rtcLog - returns the natural logarithm of a number rtcRandomize - it's used to initialize the random numbers engine, in VB: Randomize **rtcRandomNext** - returns a random real number between 0 and 1, in VB: Rnd **rtcExp(power)** - returns e (the base of natural logarithms) raised to a power **rtcRound**(VARIANT) - rounds a variant e.g.: Round(5.5) = > 6**vbaPowerR8**(number1,number2) - pow 2 real numbers: number1 ^ number2 **FnLenVar** - returns the length of variable **vbaR8Sgn** - returns an integer indicating the sign of a number; Sgn(number) returns 1 if number >0; 0 if number = 0 or -1 if number <0**vbaFPInt**, **vbaFPFix** - returns the integer portion of a number; - the difference between Int and Fix is that if number is negative, Int returns the first negative integer less than or equal to number, whereas Fix returns the first negative integer greater than or equal to number, In VB: Int/Fix API for file: **rtcFreeFile** = free file returns a filenumber that isn't in used, it is an integer and can be used to open files (in VB: hfile = FreeFile) vbaFileOpen - open a file Translated in VB: Open "c:\projectana\superpa.lic" for input as hfile vbaLineInputStr - read a line from file in a string; in VB: Line Input #hfile, BufferAddress **vbaInputFile** - reads data from files and stores the file data in your program's variables and controls In VB: Input #hfile, BufferAddress1, BufferAddress2... **vbaPrintFile** - write in a file, similar syntax with Input

```
vbaGet3 - reads data from an open disk file into a variable
In VB: Get hfile, long reading begins, variable
 vbaPut3 - writes data from a variable to a disk file
In VB: Put hfile, long writing begins, variable
rtcFileLen, rtcFileLength - returns the length of file (in VB: FileLength =
LOF(hfile))
rtcEndOfFile - will returns in ax 0 if is not end of file else 0FFFFh (-1)
 vbaFileClose - close a file (in VB: Close hfile)
 vbaFileCloseAll - close all file (in VB: Close)
rtcFileSeek(hfile, position) - set and get the current position within a file
rtcKillFiles - delete a file (in VB: Kill "name of file")
rtcFileReset - the Reset statement closes any open files and writes the
contents to disk
- this statement operates the same as the Close statement without
parameters
rtcFileLocation - this function returns the current position of the file
pointer within a file opened
with the Open statement (in VB: Position = Loc(hfile))
rtcFileAttributes - get or set the file attribute (in VB: iMode =
FileAttr(hfile, 1)
- this will get the mode for which the file is opened)
  vbaFileLock - controls access by other processes to all or part of a file
opened using
the Open statement
In VB: Lock/Unlock hfile, recordrange 'recordrange = the range of records
to lock or unlock
rtcFileCopy - copy a file
In VB: FileCopy "source", "destination"
  vbaNameFile - rename a file
In VB: Name "old" As "new"
```

# API for registry:

rtcDeleteSetting - delete a registry setting as well as the registry key
In VB: DeleteSetting capplication, csection,Key
capplication - this string setting, which is contained in the upper key of the
applications setting,
is one that you would like to delete

csection - this string setting contains the section of the registry that contains the key that you want to delete

Key - this optional parameter contains the name of the key that you want to delete; if this parameter is left empty, all of the keys in the named section are deleted

If the named section or key does not exist, the DeleteSetting function takes no action, nor does it

returns an error

Ex.: DeleteSetting "API Viewer", "Options", "View"

**rtcGetSetting** - allows you to retrieve the value of a specified registry key In VB: GetSetting capplication, esection, key, cDefault

capplication - this string setting contains the upper key of the applications setting that you would

like to retrieve

csection - this string setting contains the section of the Registry that contains the key you want

to retrieve

key - this string setting contains the name of the key whose value you want to retrieve

cDefault - this parameter is used to supply your application with a default value if the key in the

specified section does not exist (optional)

The GetSetting function returns a Variant value containing the value of the key; if the key is not found,

the cDefault value is returned

Ex.: vValue= GetSetting("API Viewer", "Options", "View","")

**rtcGetAllSettings** - allows you to retrieve all of the Registry keys and their settings for a specified

application

In VB: GetAllSettings capplication, esection

capplication - this string value contains the upper key of the applications setting that you would

like to retrieve

csection - this string setting contains the name of the section of the registry whose values you

want to retrieve

The GetAllSettings function returns a two-dimensional array of Variant

values. This array contains the

keys as well as the values from the named section of the Registry. If the value is not found, the function

returns a Null Variant value.

Ex.: vValue= GetAllSettings("API Viewer", "Options")

**rtcSaveSetting** - allows you to save a key and its value to the Registry (If the key did not previously

exist, it is created.)

In VB: SaveSetting capplication, esection, key, value

value - a string witch specify new value

#### Date:

In VB a date is stored as double (qword)

**rtcGetTimer** - returns a single representing the number of seconds elapsed since 12:00 AM (midnight)

In VB: Timer

rtcGetDateVar/rtcGetPresentDate - read current system date

In VB: Date

rtcGetDateBstr - returns offset of a string with current date

rtcGetTimeVar - reads current system time

In VB: Time

rtcGetTimeValue - returns a variant (Date) containing the time

In VB: TimeValue(time)

rtcGetCurrentCalendar - get the current calendar - used in

rtcGetPresentDate; any instant in time

can be represented as a set of numeric values using a particular calendar

rtcDateVar - copy a date value from a qword (double) to st(0),

the offset must be fixed with +8 to see the real date value to be set

rtcSetDateVar - set a variable of type date with a value

**rtcFileDateTime** - returns a Variant (Date) that indicates the date and time when a file was

created or last modified, in VB: FileDateTime(pathname)

\_vbaDateStr - has as parameter a unicode string with the date, set st(0) to date from the string

**rtcDateAdd** - returns a date to which a specified time interval has been added

In VB: NewDate = DateAdd("m", 1, Date) ' add 1 to month to Date

rtcDateDiff - returns the number of intervals between two dates

DiffADate = "Days from today: " & DateDiff("d", Now, theDate) ' returns the number of days ("d") between

current date and other date

rtcDatePart - returns the specified part of a given date

GetQuarter = DatePart("q", TheDate) ' displays the quarter of the year in which it occurs

**rtcPackDate** - returns a Variant of subtype Date for a specified year, month, and day

In VB:

Dim MyDate1, MyDate2

MyDate1 = DateSerial(1970, 1, 1) 'returns January 1, 1970

MyDate2 = DateSerial(1990 - 10, 8 - 2, 1 - 1) ' returns May 31, 1980

**rtcPackTime** - in VB: TimeSerial(time) - same thing with rtcPackDate butt for time

rtcGetDateValue - returns a Variant of subtype Date

In VB:

Dim MyDate

MyDate = DateValue("September 11, 1963") ' returns a date

**rtcGetDayOfMonth** - returns a whole number between 1 and 31, inclusive, representing the day of the month

In VB:

Dim MyDay

MyDay = Day("October 19, 1962") ' MyDay contains 19

rtcGetHourOfDay - Hour(time), rtcGetMinuteOfHour - Minute(time),
rtcGetMonthOfYear

- Month(time), rtcGetSecondOfMinute - Second(time),

rtcGetDayOfWeek - GetDayOfWeek(time),

rtcGetYear - Year(time) - self explain

rtcMonthName,rtcWeekdayName - returns a string indicating the
specified month/weekday

In VB:

Dim MyVar

MyVar = MonthName(10, True) ' MyVar contains "Oct"

Other API:

**rtcChoose** - selects and returns a value from a list of arguments

In VB: Choose(index, choice-1[, choice-2, ... [, choice-n]])

Choose returns a value from the list of choices based on the value of index

rtcCurrentDir - returns a Variant (String) representing the current path

In VB: CurDir[(drive)]

**rtcDir** - returns a string representing the name of a file, directory, or folder that matches a

specified pattern or file attribute, or the volume label of a drive

In VB: Dir(pathname, attributes)

Exemples:

MyFile = Dir("C:\WINDOWS\WIN.INI") ' returns "WIN.INI" if it exists

MyFile = Dir("C:\WINDOWS\\*.INI") ' returns the name of first file with ini extension

rtcAppActivate - makes a windows focus

In VB: AppActivate "title", wait time

rtcSendKeys - sends key strokes to current application

In VB: SendKeys "string", wait

rtcChangeDir - change the current directory

In VB: ChDir "path"

rtcMakeDir - makes a directory

In VB: MkDir "path"

rtcRemoveDir - removes a directory

In VB: MkDir "path"

RtcMsgBox(VARIANT:String:"Nope! That's not right",

Integer:0, VARIANT:String:"Wrong", VARIANT....)

- create a MessageBox with title "Wrong" and message "Nope! That's not right"

rtcBeep - beep on internal speaker, in VB: Beep

\_\_vbaNew2(ADDR offset FormDescriptor\_0\_, ADDR Form1Instance) - create a new VB form,

call the routine Form.Initialize

**rtcInputBox** - displays a prompt in a dialog box, waits for the user to input text or click a button,

and returns a String containing the contents of the text box

In VB:

Serial\$ = InputBox("Enter the working code given by Trends", "Enter Working Code")

rtcShell - runs an executable program and returns a Variant (Double)

representing the program's task ID if successful, otherwise it returns zero In VB: Shell(pathname[,windowstyle]) **rtcCommandVar** - reads command line (like GetCommandLineA) In VB: String CommandLine = Command vbaHresultCheckObj - checks the result of any operation made with a object; the operation can be closing of the About box, after the timer has elapsed, this usually come after a operation (command) made with a object vbaExceptHandler - exception handler for Visual Basic, this one is called when we have a bug, In VB: On Error GoTo CantReadF1 vbaSetSystemError - has a parameter witch holds system code \_vbaExitProc - called at the end of a procedure **vbaEnd** - close the program **rtcQBColor**(color) - set the color, translated from QBColor(color) rtcRgb - returns a long whole number representing an RGB color value Syntax: RGB(red, green, blue) **rtcVarFromError** - returns the error message that corresponds to a given error number Syntax: Error[(errornumber)] vbaSetSystemError(system code) - set the system error code **rtcSwitch** - evaluates a list of expressions and returns a Variant value or an expression associated with the first expression in the list that is True. Syntax: Switch(expr-1, value-1[, expr-2, value-2 ... [, expr-n, value-n]]) rtcDoEvents - yields execution so that the operating system can process other events rtcEnvironVar - returns the String associated with an operating system environment variable API for objects: 1. **vbaVarSetVar** - assigns an object reference to a variable or property, or associates a procedure reference with an event In VB: Dim fso ' define a variant

Set fso = CreateObject("Scripting.FileSystemObject")

'CreateObject - creates and returns a reference to an ActiveX object

'Syntax is: CreateObject(class,[servername])

Will become:

rtcCreateObject2(local\_var,class,servername)

\_vbaVarSetVar(receiver,local\_var) ' set receiver as local\_var

2. \_\_vbaVarSetObjAddref/\_\_vbaObjSetAddref

In VB:

Dim MyObject

Set MyObject = Nothing 'the Nothing keyword is used to disassociate an object variable

' from any actual object

3. **rtcCallByName** - executes a method of an object, or sets or returns a property of an object,

Syntax: CallByName(object, procname, calltype,[args()])

In VB:

CallByName Text1, "MousePointer", vbLet, vbCrosshair

Result = CallByName (Text1, "MousePointer", vbGet)

CallByName Text1, "Move", vbMethod, 100, 100

'where Text1 is the name of one TextBox (object)

4. **rtcGetObject** - returns a reference to an object provided by an ActiveX component

Syntax: GetObject([pathname] [, class])

Use the GetObject function to access an ActiveX object from a file and assign the object to an

object variable

Dim MyObject As Object

Set MyObject = GetObject("C:\DRAWINGS\SAMPLE.DRW",

"FIGMENT.DRAWING")

' In the example, FIGMENT is the name of a drawing application and DRAWING is one of the

' object types it supports

\_TextBox:: AddRef returns DWORD:1 - AddRef increment reference count of a object (instantiation)

**Zombie** AddRef Function takes the Object Reference.

In this function the parent object (in this case Form) is passed as a

parameter

and uses AddRef to increment reference count of the object (instantiation). Since COM objects are responsible for their lifetime, the resources they use are

allocated until the reference count is 0, when it reaches 0 the objects enter zombie state & can be deallocated to free resources.

5. **vbaObjSet** - set a object variable

00401C52 MOV EAX, DWORD PTR DS: [ESI]; use current instance

00401C54 PUSH ESI; Form1 instance

00401C55 CALL DWORD PTR DS:[EAX+304]; get the ID of Text2, if is Text1 would be 2FC

00401C5B LEA ECX,DWORD PTR SS:[EBP-20]

00401C5E PUSH EAX; the object identifier

00401C5F PUSH ECX; address of a variable witch will keep the object identifier

00401C60 CALL MSVBVM60.\_\_vbaObjSet; set a object variable, will returns in eax the new value of object

00401C66 MOV ESI,EAX

00401C68 LEA EAX, DWORD PTR SS: [EBP-1C]

00401C6B PUSH EAX

00401C6C PUSH ESI; the object identifier

00401C6D MOV EDX,DWORD PTR DS:[ESI]

00401C6F CALL DWORD PTR DS:[EDX+A0];

; This call is a Visual Basic command

; we have 0A0 so the command is Text2.Text - get text from Text1

; Can be used other register

**rtcErrObj** - no parameter, returns offset of a error object, after that will be set a object with the

returned value

- 6. **vbaFreeObj** free an object variable (set object to 0)
- push in ecx the address of object to be free
- 7. \_\_vbaFreeObjList(number\_of\_objects, Object1,Object2,...) free a list of objects (variables)

VB Commands Previous Top

How VB commands looks:

push 00; the value to be set or offset of variable witch keep the result

push eax; object instance

mov edx, dword ptr [eax]

call dword ptr [edx+000001BC]; set a From visibility to False

(NagForm. Visible = False)

Visual Basic 6.0 commands reference:

00010h - unload a form, in VB "Unload Form1"

00050h - read the aplication path, in VB App.Path

Exemple: hfile = FreeFile

Open App.Path + "\data.cfg" For Input As hfile

00054h - changing the caption property for any object which has one. An example of how this knowledge

may be useful is if a program has an annoying "Not Registered" in the title bar of a form;

- this is used even when you change the caption of any label

(mainForm.Caption = "Blah Blah v1.0 - Unregistered")

00064h - set color of background form

00074h - enabling/disabling a menu item (mnuRegister.Enabled = True)

0008Ch - set state of a button (Command1.Enabled = False or True)

00094h - making a command button visible/invisible (Command1.Visible = True)

0009Ch - making labels visible/invisible (Label1.Visible = True)

000A0h - get text for a TextBox

000A4h - set text for a TextBox

000E0h - read state of a Radio buton (Option1. Value)

01BCh - set the form visibility (NagForm. Visible = True or False)

02B0h - show a form (Form.Show)

02B4h - hide a form (Form.Hide)

0204h - Text1.SetFocus - set focus Text1

0040h - SavePicture Image, "TEST.BMP" ' save picture to file

0044h - LoadPicture("PARTY.BMP")

0104h - Set Command1.DragIcon = LoadPicture("MYICON.ICO") ' set

# drag icon

0164h - Set Form1.Icon = LoadPicture("MYICON.ICO")

0058h - Clipboard.SetData LoadPicture("PARTY.BMP")

0060h - Clipboard.SetText "Text"

000Ch - File1.FileName = "\*.\*"

#### PICTURE BOX:

0154h - **Set Picture** = LoadPicture("PARTY.BMP")

0288h - Form1.Picture1.PSet (X,Y) - draw a point

028Ch - Form1.Picture1.Scale (X1, Y1)-(X2, Y2) - scale the image

027Ch - Form1.Picture1.Line(X1, Y1)-(X2, Y2)- draw a line